Subscribe to our newsletter & get \$5 Bazaar coupon!

Seeed Categor

Bazaar / Industry Spotlight / Machine Vision / Optor Cam2pc Visual-Inertial SLAM







Optor Cam2pc Visual-Inertial SLAM

SKU 101990260 Read all reviews f 💆 🙃 🦻 😇

1 ADD TO CART

Q Sign in 📜

Description

Optor Visual Inertial Camera is a general vision sensor designed for visual algorithm developers. Providing abundant hardware control interface and data interface aimed to reduce development threshold with reliable image and inertial data.


Hardware Specifications

Physical Dimensions



Camera Coordinate System between Left camera and IMU






• Hardware Performance and Specifications

	CMOS	IMU
Туре	MT9V034	MPV-6050
Exposure Mode	Global shutter	-
Controller IC	CY68013	STM-32
FPS	24-65fps	200fps
Supported Resolution	320*240/640*480/752*480	-
Firmware Update	Firmware Update Supported By Windows Software	_
Baseline	10cm	-
Lens physical interface	M12 Lens interface	-
Lens Specifications	2.1mm/150°+6mm/60°	-
Data interface	Usb 2.0	
Data Delay	(1/Current_FPS)s	100us
Frame Synchronization	Stereo Synchronization Triggered By Camera Driver	-

Product Feature

• IMU zero bias calibration program, Zero bias initialization algorithm of DMP, High precision 6-DOF data, Minimum attitude drift.



• Stereo optical parameters already accurately calibrated



• The lens seat rifled through special processing, to ensure the camera would not loosen in the long-term delivery and the lens can be replaced.



- SDK needs no compilation,no special dependency libraries(only relay on libusb)
- stable and reliable ROS driver
- Ubuntu 16/14 supported

Technical Details

Dimensions0mm x 0mm x 0mm Weight G.W 140g Battery

Part List

Camera Module1 usb cable

ECCN/HTS

HSCODE9031809090

Documents

Documents

Reviews

January 11,2018 by Anonymous User

Questions and Answers

Is there a working live-cd image? I have not gotten the camera to run, because always something with the drivers does not fit or are not installable.

Reply upvote (0)

 $Hi \ Drebert \sim Unfortunately, we do not have such image. Please follow the guide link below. It will helps you with the driver step by step. Regards.$ ==== https://github.com/optor-vis/vi-stereo-==dividing line=:

v1/blob/master/optor_VI_Sensor_SDK_V1.0/Optor%20User%20Manual.pdf

Seeed Techsupport Team on Feb 28,2018 09:46 AM

Reply upvote (0)

0 How the trajectory and 6DOF been calculated, solely based on IMU or a data fusion of IMU+ camera frame features?

Hi Mary~ We only provide the topic data between IMU and the camera.Regards

Seeed Techsupport Team on Feb 28,2018 09:49 AM Reply upvote (0)

 $Some \ questions \ about \ synchronization: \\ *\ \" Stereo \ Synchronization \ Triggered \ By \ Camera \ Driver \" \ is \ not \ really \ clear \ to \ me. \ How \ accurate \ is \ the \ sync, \ and \ accurate \ is \ the \ sync, \ according to \ the \ sync, \ according to \ synchronization \ Triggered \ By \ Camera \ Driver \" \ is \ not \ really \ clear \ to \ me. \ How \ accurate \ is \ the \ sync, \ according to \ synchronization \ Triggered \ By \ Camera \ Driver \" \ is \ not \ really \ clear \ to \ me. \ How \ accurate \ is \ the \ sync, \ according to \ synchronization \ Triggered \ By \ Camera \ Driver \" \ is \ not \ really \ clear \ to \ me.$ what is the max time difference between the cameras? Do the camera's stay in sync or are they only synchronized once (and thus prone to drift)? * Can the IMU data be synced with the camera frames, eg because both the IMU data and the frames have timestamps from the same clock?

helium_2 on Jun 06,2017

Hi Remco~ 1.We've not test the time difference between the cameras. 2.Always stay in sync. 3.The IMU data is synced with the camera frames and they have the same clock. Regards

Seeed Techsupport Team on Feb 28,2018 09:53 AM

Optor Cam2pc Visual-Inertial SLAM SKU 101990260 f 😗 🙃 🦻 🎳

Read all 1reviews

IN STOCK

1 Available

ADD TO CART

Reply upvote (0)

Technical Details

Questions and Answers

Downloaded from Arrow.com.

Downloaded from Arrow.com.

G

I♠ Contact Support